experiment-ver2

November 8, 2021

```
[1]: import datetime
     from datetime import timedelta
     import os
     import wget
     import pandas as pd
     import urllib.request
     today = datetime.date.today()
     yesterday = today - timedelta(days = 1)
     print(today)
     print(yesterday)
    2021-11-08
    2021-11-07
[2]: today = str(today)
     print(today[5:7])
    11
[3]: daysinmonth = int(str(today)[-2:])
     if daysinmonth < 7:</pre>
         daysinweek = daysinmonth
     else:
         daysinweek = 7
     print(daysinmonth)
     print(daysinweek)
    7
[4]: #convert to string for managing files
     yesterday = str(yesterday)
     today = str(today)
[5]: #define sensor_id here
     sensor_id = "12776407"
```

```
link = 'https://api-rrd.madavi.de/data_csv/csv-files/'+ today + '/
     #check if todays data already downloaded
    def check():
        filename = 'data-esp8266-'+sensor id+'-'+today+'.csv'
        files = os.listdir()
        for file in files:
            if str(file) == str(filename):
                os.remove(filename) # if exist, remove it
        return
[6]: # check if todays data is available or not, if not then download latest data of
     \rightarrow yesterday
    req = urllib.request.Request(link)
    try:
        urllib.request.urlopen(req)
        check()
        filename = 'data-esp8266-'+sensor_id+'-'+today+'.csv'
        print("Todays data will be downloaded!")
        wget.download(link)
    except urllib.error.URLError as e:
        print(e.reason)
        print("Todays data isn't updated on server")
        print("Downloading yesterdays data")
        today = yesterday
        filename = 'data-esp8266-'+sensor_id+'-'+today+'.csv'
        check()
        link = 'https://api-rrd.madavi.de/data_csv/csv-files/'+ today + '/

data-esp8266-'+sensor_id+'-'+ today + '.csv'

        wget.download(link)
    print(today)
    print(yesterday)
    print(filename)
    Todays data will be downloaded!
    100%
    [...]
    33165 / 331652021-11-08
    2021-11-07
    data-esp8266-12776407-2021-11-08.csv
[7]: #create list that contains 7 days since today
```

dayformat = "%Y-%m-%d"

week = []

today = datetime.datetime.strptime(today, dayformat)

```
for i in range(daysinweek):
          week.append(today - timedelta(days = i))
          week[i] = str(week[i])[:10]
      print(week)
      #create list that contains 30 days since today
      month = []
      for i in range(daysinmonth):
          day = today - timedelta(days=i)
          day = day.strftime('%Y-%m-%d')
          stoday = today.strftime('%Y-%m-%d')
          if int(day[5:7]) < int(stoday[5:7]):</pre>
              break
          month.append(day)
          month[i] = str(month[i])[:10]
      print(month)
      yesterday = str(yesterday)[:10]
      today = str(today)[:10]
     ['2021-11-08', '2021-11-07', '2021-11-06', '2021-11-05', '2021-11-04',
     '2021-11-03', '2021-11-02']
     ['2021-11-08', '2021-11-07', '2021-11-06', '2021-11-05', '2021-11-04',
     '2021-11-03', '2021-11-02', '2021-11-01']
 [8]: #read dataframe of today
      df = pd.read_csv(filename,sep=';')
 [9]: #convert Time string to datetime type
      format = "%Y/%m/%d %H:%M:%S"
      def convert_datetime(dt_string):
          dt_object = datetime.datetime.strptime(dt_string, format)
          return dt_object
      df['Time'] = df['Time'].apply(convert_datetime)
[10]: #plotting latest data of one day in plotly
      import plotly.graph_objects as go
      from plotly.subplots import make_subplots
      def plotting(df):
          # Create figure with secondary y-axis
          fig = make_subplots(specs=[[{"secondary_y": True}]])
          # Add traces
          fig.add_trace(
```

```
go.Scatter(x=df['Time'], y=df['SDS_P1'], name="PM2.5", u
 ⇔line=dict(color='#7355A3')),
        secondary_y=False,
    )
    fig.add_trace(
        go.Scatter(x=df['Time'], y=df['SDS_P2'], name="PM10", __
 →line=dict(color='#E47988')),
        secondary_y=True,
    )
    # Add figure title
    fig.update_layout(
        title_text="PM2.5 & PM10",
        height=600
    )
    # Set x-axis title
    fig.update_xaxes(title_text="Time")
    # Set y-axes titles
    fig.update_yaxes(title_text="PM2.5", secondary_y=False)
    fig.update_yaxes(title_text="PM10", secondary_y=True)
    fig.show()
def plotting_temperature_humidity(df):
    # Create figure with secondary y-axis
    fig = make_subplots(specs=[[{"secondary_y": True}]])
    # Add traces
    fig.add_trace(
        go.Scatter(x=df['Time'], y=df['Temp'], name="Temperatur", __
⇔line=dict(color='#E47988')),
        secondary_y=False,
    )
    fig.add trace(
        go.Scatter(x=df['Time'], y=df['Humidity'], name="Luftfeuchtigkeit", u
⇔line=dict(color='#53a7fc')),
        secondary_y=True,
    )
    # Add figure title
    fig.update_layout(
```

```
title_text="Temperatur und Luftfeuchtigkeit",
    height=600
)


# Set x-axis title
fig.update_xaxes(title_text="Time")

# Set y-axes titles
fig.update_yaxes(title_text="Temperatur [°C]", secondary_y=False)
fig.update_yaxes(title_text="Luftfeuchtigkeit [%]", secondary_y=True)


fig.show()

plotting(df)
plotting_temperature_humidity(df)
```

PM2.5 & PM10



Temperatur und Luftfeuchtigkeit




```
[11]: #WEEKLY and MONTHLY datas fetching
      #Check if folder is already exists -> if yes then delete it
      import shutil
      import glob
      def checkfolder(folder):
          path = './' + folder
          isdir = os.path.isdir(path)
          if isdir == True:
              shutil.rmtree(path)
              print("% s removed successfully" % path)
          else:
              print("Creating " + folder)
      #download weekly datas
      def download_datas(folder,timeinterval):
          path = './' + folder + ''
          os.mkdir(folder)
          for date in timeinterval:
              date=str(date)
              link = 'https://api-rrd.madavi.de/data_csv/csv-files/'+ date + '/

data-esp8266-'+sensor_id+'-'+ date + '.csv'

              wget.download(link, path)
      def join_csvfiles(folder):
          path = './' + folder + ''
          all_files = glob.glob(os.path.join(path, "*.csv"))
          df_from_each_file = (pd.read_csv(f, sep=';') for f in all_files)
          df_merged = pd.concat(df_from_each_file, ignore_index=True)
          df_merged.to_csv("./"+folder+"/merged.csv")
      checkfolder("week")
      download_datas("week",week)
      join_csvfiles("week")
      df_week = pd.read_csv("./week/merged.csv",sep=",")
      #plotting latest data of one week in plotly
      df_week['Time'] = df_week['Time'].apply(convert_datetime)
      plotting(df_week)
      plotting_temperature_humidity(df_week)
      #fetch and plot data of one month
      checkfolder("month")
```

```
download_datas("month", month)
join_csvfiles("month")
df_month = pd.read_csv("./month/merged.csv",sep=",")
df_month['Time'] = df_month['Time'].apply(convert_datetime)
plotting(df_month)
plotting_temperature_humidity(df_month)
```

./week removed successfully 100% [...] 35587 / 35587







./month removed successfully

100% [...] 23893 / 23893





Temperatur und Luftfeuchtigkeit



```
[12]: #find last month and export to string
last_month = int(str(today)[5:7]) #10
last_month = 12 if last_month == 1 else last_month-1
if len(str(last_month)) == 1:
    last_month = "0" + str(last_month) #09

last_month = str(last_month)
print(last_month)
```

```
[13]: #download data of last month
      #https://api-rrd.madavi.de/data_csv/2021/10/data-esp8266-12776407-2021-10.zip
      last month link = "https://api-rrd.madavi.de/data_csv/2021/"+last_month+"/


→data-esp8266-"+sensor_id+"-2021-"+last_month+".zip"
      checkfolder(last month)
      path = './'+last_month
      os.mkdir(last month)
      wget.download(last_month_link, path)
     ./10 removed successfully
     100%
     [...]
     307021 / 307021
[13]: './10/data-esp8266-12776407-2021-10.zip'
[14]: from zipfile import ZipFile
      dir = os.listdir(path)
      file = dir[0]
      path = path+"/"+file
      # open the zip file in read mode
      with ZipFile(path, 'r') as zip:
          # extract all files to directory
         zip.extractall(last_month)
      os.remove(path) #delete zip file
[15]: join_csvfiles(last_month)
[16]: df_last_month = pd.read_csv("./"+last_month+"/merged.
      df last month.head()
[16]:
        Unnamed: 0
                                    Time durP1 ratioP1 P1 durP2
                                                                    ratioP2 P2 \
                 0 2021/10/01 00:00:31
      0
                                            NaN
                                                     NaN NaN
                                                                NaN
                                                                         NaN NaN
      1
                  1 2021/10/01 00:02:56
                                            NaN
                                                     NaN NaN
                                                                NaN
                                                                         NaN NaN
      2
                  2 2021/10/01 00:05:22
                                            NaN
                                                     NaN NaN
                                                                NaN
                                                                         NaN NaN
      3
                  3 2021/10/01 00:07:49
                                            NaN
                                                                NaN
                                                     NaN NaN
                                                                         NaN NaN
                  4 2021/10/01 00:10:14
                                            {\tt NaN}
                                                     NaN NaN
                                                                NaN
                                                                         NaN NaN
        SDS_P1 SDS_P2 ... BMP_pressure BME280_temperature BME280_humidity \
          6.40
                  3.35 ...
      0
                                     NaN
                                                         NaN
                                                                          NaN
          5.22
                  2.78 ...
      1
                                     NaN
                                                         NaN
                                                                          NaN
      2
          8.35
                  3.00 ...
                                     NaN
                                                         NaN
                                                                          NaN
      3
          8.15
                  3.15 ...
                                     NaN
                                                         NaN
                                                                          NaN
      4
           6.43
                   2.97 ...
                                                                          NaN
                                     NaN
                                                         NaN
```


| | BME280_pressure | Samples | Min_cycle | Max_cycle | Signal | HPM_P1 | HPM_P2 |
|---|-----------------|---------|-----------|-----------|--------|--------|--------|
| 0 | NaN | 5049547 | 28 | 20025 | -50 | NaN | NaN |
| 1 | NaN | 5049623 | 28 | 20399 | -44 | NaN | NaN |
| 2 | NaN | 5050039 | 28 | 20472 | -47 | NaN | NaN |
| 3 | NaN | 5051385 | 28 | 20029 | -45 | NaN | NaN |
| 4 | NaN | 5050198 | 28 | 20055 | -47 | NaN | NaN |

[5 rows x 25 columns]


PM2.5 & PM10

```
[17]: df_last_month['Time'] = pd.to_datetime(df_last_month['Time'], errors='coerce')
      plotting(df_last_month)
     plotting_temperature_humidity(df_last_month)
```





Temperatur und Luftfeuchtigkeit




```
[18]: import requests_html
      months = []
      with requests_html.HTMLSession() as s:
          try:
              r = s.get('https://api-rrd.madavi.de/csvfiles.php?

→sensor=esp8266-'+sensor id)
              links = r.html.links
              for link in links:
                  if link[-3:] == "zip":
                      months.append(link)
          except:
              pass
      print(months)
     ['data_csv/2021/07/data-esp8266-12776407-2021-07.zip', 'data_csv/2021/05/data-
     esp8266-12776407-2021-05.zip', 'data_csv/2020/12/data-
     esp8266-12776407-2020-12.zip', 'data_csv/2021/10/data-
     esp8266-12776407-2021-10.zip', 'data_csv/2021/09/data-
     esp8266-12776407-2021-09.zip', 'data_csv/2021/08/data-
     esp8266-12776407-2021-08.zip']
[19]: #download all zip files of past months
      checkfolder("all")
      path = './all'
      os.mkdir("all")
      for link in months:
          download_link = "https://api-rrd.madavi.de/"+link
          wget.download(download_link, path)
     ./all removed successfully
     100%
     [...]
     330452 / 330452
[20]: #extract zip files
      days = os.listdir("./all")
      for day in days:
          path="./all/"+day
          with ZipFile(path, 'r') as zip:
              # extract all files to directory
              zip.extractall("all")
          os.remove(path)
```


```
#download datas of this month to the all-folder
for date in month:
    path = './all'
    date=str(date)
    link = 'https://api-rrd.madavi.de/data_csv/csv-files/'+ date + '/
    data-esp8266-'+sensor_id+'-'+ date + '.csv'
    wget.download(link, path)
```

100% [...] 23893 / 23893

```
[21]: join_csvfiles("all")
   df_all = pd.read_csv("./all/merged.csv",sep=",")
   df_all['Time'] = df_all['Time'].apply(convert_datetime)
   plotting(df_all)
   plotting_temperature_humidity(df_all)
```







[]: